

E-687 | ESD3 REFRIGERANT TYPE DRYER CONTROLLER FILTER CHANGE ALARM RESET

This alarm is caused by the counter of the controller for filter element change time. After you change the filter element you can follow the procedures below for counter reset

There're two different ways for filter time counter reset

For controllers with new version software

- 1- Enter the security password as 10
- 2- Find the "Filter Change" menu under "Time Parameters" menu
- 3- Push the UP and DOWN arrows at the same time.
- 4- FILTER TIME will be reset to 0.0

For controllers with old version software

- 1- Connect the 1 numbered and 27 numbered terminals with a cable on electrical panel
- 2- Enter the password as 10
- 3- Find the "Filter Change" menu under "Time Parameters" menu
- 4- Push the UP and DOWN arrows at the same time.
- 5- FILTER TIME will be reset to 0.0

After filter time reset process, please remove the cable connection you applied between the 1 and 27 numbered terminals.

This parameter cannot be edited unless Security Password is entered or Maintenance Password is entered

Security Password: 10

Maintenance Password: 1071