

Logic 9 Maintenance Reset

FIRST OIL CHANGE

1. Hold ENTER until PA 1 appears in the screen.
2. Arrow down to PA 2
3. Push ENTER
4. Use up arrow until #3 appears in the screen push ENTER until three #3's show on screen.
5. Arrow down to #5 P – F shows on the screen push ENTER.
6. Arrow down to #5 COF push Enter use up arrow to change to 2000 HRS push ENTER then down to #5 C--- push ENTER and change to 2000 HRS.

REGULAR SCHEDULED OIL CHANGE

1A. Repeat the first 4 steps.

2A. Arrow down to #9 Reset

3A. Push ENTER to P – F push Enter CAF will appear and then hold ENTER until CAF blinks

Arrow down to next filter and repeat step 3A until all parameters are reset.

When finished arrow down to home screen.